

<b>AUDIO RECEIVER BRAND</b>	<b>AUDIO RECEIVER CODES</b>
AIWA	759, 762, 771, 836, 839, 842, 851, 860
APEX	436
BOSE	672
CARVER	745, 825
CITIZEN	746, 826
CRITERION	448
DENON	723, 737, 803, 817, 852
DELPHI	708
FISHER	734, 741, 814, 821
GOLDSTAR	686, 766
HARMON KARDON	724, 738, 804, 818
JVC	710, 733, 739, 790, 813, 819
KENWOOD	603, 683, 728, 736, 748, 752, 808, 816, 828, 832, 869
KOSS	415
MAGNAVOX	716, 734, 796, 814
MARANTZ	608, 744, 688, 824
MITSUBISHI	877
NAD	641, 659, 721, 739, 743
NORCENT	907
ONKYO	725, 731, 732, 805, 811, 812, 892
OPTIMUS	587, 667, 668, 669, 670, 671, 672, 674, 713, 667, 747, 748, 749, 751, 752, 754, 793
PANASONIC	730, 735, 791, 810, 815, 823, 824, 825, 863, 864
PHILIPS	734, 743, 744, 745, 755, 814, 823, 824, 825
PIONEER	757, 837, 866, 867, 878, 893
RADIOSHACK	706, 754, 793, 806, 865, 866, 867, 868, 875, 878, 879
RCA	449, 637, 692, 701, 715, 747, 717, 726, 772, 781, 795, 827, 845, 866, 867, 870, 871, 872, 875, 878, 879, 895
REALISTIC	742, 822
RS ORIGINAL	626, 674, 713, 726
SABA	894
SAMSUNG	454
SANYO	625, 705
SCOTT	688, 768

SHARP	591, 604, 729, 671, 679, 684, 809
SHERWOOD	626, 706, 726, 806, 858, 859
SONY	323, 698, 705, 717, 718, 719, 753, 754, 755, 756, 778, 779, 785, 797, 798, 799, 833, 834, 835, 836, 843, 909
TEAC	630, 727, 710, 807, 855, 856, 857

TECHNICS	711, 730, 735, 743, 791, 810, 815, 823, 863, 864
TEVION	448
VENTURER	665, 745
XM RADIO	708
YAMAHA	721, 722, 758, 760, 761, 766, 767, 768, 769, 801, 802, 838, 840, 841, 846, 847, 848, 849
ZENITH	405, 596, 650, 669, 676, 679, 685, 686, 704, 730, 734, 749, 759, 765, 766, 770, 784, 787, 814, 850

<b>CABLE BOX BRAND</b>	<b>CABLE BOX CODES</b>
ABC	381, 382, 383, 384, 385, 386, 387, 461, 462, 463, 464, 465, 466
ADELPHIA	512, 596
ALLEGRO	444, 445, 524, 525
AMERICAST	447, 527
ANTRONIX	388, 389, 468, 469
ARCHER	388, 389, 390, 391, 468, 469, 470, 471
AT&T	511
BELL SOUTH	527
CABLETENNA	388, 468
CABLEVIEW	388, 468
CENTURY	391, 471
CITIZEN	391, 471
COLOUR VOICE	392, 393, 472, 473
COMCAST	511
COMTRONICS	474, 475
CONTEC/CONY	396, 476
DIGITAL MUSIC EXPRESS	514
EASTERN	397, 477
EVERQUEST	474
GARRARD	391, 471
GC ELECTRONICS	389, 469
GEMINI	398, 399, 478, 479, 536

<b>GE</b>	469, 549
<b>GENERAL INSTRUMENT</b>	383, 429, 431, 433, 434, 438, 448, 449, 450, 451, 461, 463, 464, 465, 509, 511, 513, 514, 518, 528, 529, 530, 531
<b>HAMLIN</b>	400, 401, 402, 461, 480, 481, 482
<b>HITACHI</b>	383, 463
<b>HYTEX</b>	382, 462
<b>JASCO</b>	391, 471
<b>JERROLD</b>	381, 383, 384, 385, 387, 398, 404, 429, 430, 446, 448, 449, 461, 463, 464, 465, 478, 484, 509, 510, 511, 518, 520, 526, 528, 529
<b>MAGNAVOX</b>	405, 485

<b>MEMOREX</b>	406, 486
<b>MOTOROLA</b>	461, 463, 464, 465, 478, 484, 509, 510, 511, 513, 514, 518, 526, 528, 529, 530, 531
<b>MOVIE TIME</b>	382, 407, 462, 487
<b>NSC</b>	382, 407, 462, 487
<b>OAK</b>	382, 396, 409, 462, 476, 489
<b>PACE</b>	532
<b>PANASONIC</b>	380, 428, 460, 508
<b>PARAGON</b>	406, 486, 488
<b>PHILIPS</b>	471, 479, 485, 490, 491, 492
<b>PHILIPS/ MAGNAVOX</b>	391, 392, 393, 399, 405, 410, 411, 412, 471, 472, 473, 479, 485, 490, 491, 482, 503, 534
<b>PIONEER</b>	413, 414, 418, 478, 493, 494, 498, 506
<b>PULSAR</b>	406, 486
<b>RADIO SHACK</b>	425, 505, 525, 534
<b>RCA</b>	380, 427, 460, 471, 507
<b>REALISTIC</b>	389, 469
<b>REGAL</b>	402, 482
<b>REGENCY</b>	397, 477
<b>REMBRANDT</b>	383, 463
<b>RUNCO</b>	406, 486
<b>SAMSUNG</b>	394, 414, 474, 494
<b>SCIENTIFIC ATLANTA</b>	386, 416, 417, 418, 466, 496, 497, 498, 506, 512, 535, 596, 607
<b>SIGNAL</b>	394, 398, 474, 478
<b>SIGNATURE</b>	383, 463
<b>SL MARX</b>	394, 474
<b>SPRUCER</b>	380, 460

<b>STANDARD COMPONENTS</b>	419, 499
<b>STARCOM</b>	381, 387, 398, 461, 478, 518
<b>STARGATE</b>	394, 398, 474, 478
<b>STARSIGHT</b>	440, 507, 520
<b>STAR SIGHT CABLE SERVICE</b>	427, 507
<b>STARQUEST</b>	398, 478
<b>STAR TRAK</b>	436, 516
<b>TANDY</b>	420, 500
<b>TELEVIEW</b>	394, 474
<b>TELEWEST</b>	532
<b>TEXSCAN</b>	419, 499
<b>TIME WARNER</b>	506

<b>TOCOM</b>	384, 421, 433, 464, 501, 513, 520
<b>TOSHIBA</b>	406, 486
<b>TUSA</b>	398, 478
<b>TV86</b>	407, 487
<b>UNIKA</b>	388, 389, 391, 468, 469, 471
<b>UNITED ARTISTS</b>	382, 462
<b>UNITED CABLE</b>	381, 461
<b>UNIVERSAL</b>	388, 389, 390, 391, 422, 468, 469, 470, 471, 502
<b>VIDEOWAY</b>	424, 504
<b>VIEWSTAR</b>	395, 405, 407, 420, 475, 485, 487, 500
<b>VIDEO TECH</b>	470, 550
<b>ZENITH</b>	406, 408, 423, 437, 439, 440, 441, 442, 443, 444, 445, 447, 471, 486, 488, 503, 517, 519, 520, 521, 522, 523, 524, 525, 527, 533
<b>ZENITH NETWORK</b>	527
<b>CD PLAYER BRAND</b>	<b>CD PLAYER CODES</b>
<b>ADC</b>	580, 660
<b>ADCOM</b>	581, 634, 661, 714
<b>AIWA</b>	582, 583, 762, 662, 663, 707, 842
<b>AKAI</b>	635, 657, 750, 715, 737, 830
<b>AUDIO TECHNICA</b>	585, 665
<b>CALIFORNIA AUDIO LABS</b>	636, 716
<b>CAPETRONIC</b>	589, 669

<b>CARVER</b>	586, 587, 588, 745, 666, 667, 668, 825
<b>CASIO</b>	697, 777
<b>CITIZEN</b>	746, 826
<b>CURTIS MATHIS</b>	697, 777
<b>DENON</b>	590, 670
<b>EMERSON</b>	581, 592, 593, 661, 673
<b>FISHER</b>	587, 595, 596, 597, 638, 667, 675, 676, 677, 718
<b>GE</b>	645, 725
<b>GENEXXA</b>	592, 593, 598, 639, 673, 678, 719
<b>GOLDSTAR</b>	640, 720
<b>HARMON KARDON</b>	600, 611, 680, 691
<b>HITACHI</b>	598, 678
<b>INKEL</b>	601, 681
<b>JC PENNEY</b>	610, 697, 690, 777
<b>JVC</b>	602, 733, 682, 813
<b>KENWOOD</b>	603, 604, 605, 647, 648, 679, 683, 684, 685, 727, 728, 748, 828

<b>KRELL</b>	586, 666
<b>KYOCERA</b>	580, 660
<b>LUXMAN</b>	606, 607, 649, 658, 686, 687, 729, 738
<b>LXI</b>	592, 697, 777
<b>MAGNAVOX</b>	586, 651, 720, 666, 731, 800
<b>MARANTZ</b>	586, 608, 609, 652, 666, 688, 689, 732
<b>MCS</b>	610, 697, 690, 777
<b>MGA</b>	611, 691
<b>MISSION</b>	586, 666
<b>MITSUBISHI</b>	611, 612, 691, 692
<b>NAD</b>	641, 721, 743
<b>NAKAMICHI</b>	613, 614, 751, 693, 694, 831
<b>NEC</b>	610, 690
<b>NIKKO</b>	585, 593, 596, 665, 673, 676
<b>NSM</b>	586, 666
<b>ONKYO</b>	615, 616, 642, 731, 695, 696, 722, 811
<b>OPTIMUS</b>	587, 588, 592, 598, 604, 617, 618, 619, 620, 664, 667, 668, 671, 667, 668, 678, 684, 697, 698, 699, 700, 744, 747, 751

PANASONIC	636, 653, 660, 716, 733, 740, 820, 862
PHILIPS	586, 651, 745, 666, 731, 825
PIONEER	598, 621, 622, 639, 757, 678, 701, 702, 719, 750, 837, 876
PROTON	586, 666
QUASAR	636, 716
RADIOSHACK	668, 699, 706, 750, 786, 868, 874, 876
RCA	581, 587, 592, 623, 643, 661, 667, 703, 715, 723, 750, 764, 765, 795, 844, 845, 873, 874, 876
REALISTIC	581, 587, 589, 592, 593, 598, 609, 617, 619, 661, 667, 669, 673, 678, 689, 697, 699
ROTEL	586, 666
RS ORIGINALS	588, 626
SAE	586, 666
SAMSUNG	661, 741
SANSUI	586, 592, 624, 643, 654, 666, 704, 723, 734
SANYO	587, 625, 638, 655, 662, 667, 705, 718, 735, 742
SCOTT	581, 592, 593, 661, 673
SEARS	592, 604, 609, 679, 684, 689, 777
SHARP	604, 599, 609, 684, 679, 689
SHERWOOD	601, 609, 618, 626, 681, 689, 698, 706, 859
SHURE	610, 690
SONY	627, 628, 712, 714, 720, 707, 708, 792, 794, 800

STS	580, 660
SYLVANIA	586, 666
SYMPHONIC	629, 709
TEAC	596, 609, 619, 629, 630, 631, 676, 689, 699, 709, 710, 711, 856
TECHNICS	636, 653, 656, 740, 716, 733, 820, 862
THETA DIGITAL	651, 731
TOSHIBA	641, 721
VICTOR	602, 682
YAMAHA	585, 632, 633, 644, 665, 712, 713, 724, 766, 846
ZENITH	596, 650, 679, 704, 770, 676, 730, 759, 784, 850
<b>DVD/VCR COMBO BRANDS</b>	<b>DVD/VCR COMBO CODES</b>
BROKSONIC	394
CINEVISION	230, [405 245]

EMERSON	230, 456, [458 227]
FISHER	230, [416 267]
FUNAI	230, 456, [458 227]
GO-VIDEO	230, 407, 426, 455
HITACHI	[419 227]
INSIGNIA	[405 245]
JVC	151, 418
MAGNAVOX	456
PANASONIC	437
PHILIPS	183, 456
RCA	[409 225]
SAMSUNG	230, 455
SANYO	042, 191 [416 267]
SEARS	394
SONY	389
SYLVANIA	456, [458 227]
SYMPHONIC	456, [458 227]
TOSHIBA	902
WHITE WESTINGHOUSE	[458 227]
ZENITH	[405 245]
<b>DVR/SAT COMBO BRANDS</b>	<b>DVR/SAT COMBO CODES</b>
BELL EXPRESSVU	647, 655
DISH NETWORK	647, 655
ECHOSTAR	647, 655

HUGHES NETWORK	621
RCA	636, 653
PHILIPS	621
PROSCAN	636, 653
SAMSUNG	583
SONY	657, 659
ULTIMATE TV	653, 659
ZENITH	656
<b>TV/VCR COMBO BRANDS</b>	<b>TV/VCR COMBO CODES</b>

<b>ADMIRAL</b>	001, 115, 124, 226
<b>AIWA</b>	002, 008, 155, 227, 269
<b>AKAI</b>	254
<b>BROKSONIC</b>	085, 136, 310
<b>CANDLE</b>	014, 153
<b>CURTIS MATHES</b>	073, 133, 358
<b>DAEWOO</b>	027, 039, 054, 097, 138, [039 252] [147 257]
<b>ELECTROHOME</b>	254
<b>EMERSON</b>	002, 008, 027, 036, 039, 041, 155, 198, 227, 231, 233, 254, 264, 265, 266, 310, 325, [039 252] [147 250] [147 257]
<b>FISHER</b>	043, 209, 268
<b>FUNAI</b>	002, 008, 155, 198, 227, 231
<b>GE</b>	102, 117, 194, 342
<b>GOLDSTAR</b>	002, 008, 014, 113, 121, 153, 155, 227, 338
<b>HITACHI</b>	002, 155
<b>JVC</b>	247
<b>INFINITY</b>	062, 288
<b>KONKA</b>	157, 158, 187, 188
<b>LG</b>	002, 014, 113, 121, 153, 155, 227, 338
<b>LXI</b>	002, 155, 227
<b>MAGNAVOX</b>	001, 062, 115, 226, 288, 456
<b>MEMOREX</b>	043, 209, 268, 456
<b>PANASONIC</b>	138, 148, 374, 381
<b>PHILIPS</b>	062, 063, 212, 288, 310
<b>PHILIPS/MAGNAVOX</b>	103, 213, 226, 288
<b>OPTIMUS</b>	374, 381
<b>QUASAR</b>	138, 148, 374, 381
<b>RADIOSHACK</b>	102, 194, 227, 342
<b>RCA</b>	102, 117, 194, 342

<b>REALISTIC</b>	227
<b>SAMSUNG</b>	073, 129, 133, 358
<b>SANSUI</b>	085, 136, 310
<b>SANYO</b>	043, 209, 268
<b>SHARP</b>	001, 124, 226, 266

SONY	002, 128, 155, 380
SYLVANIA	002, 008, 155, 198, 227, 231
SYMPHONIC	002, 008, 155, 198, 227, 231
WHITE WESTINGHOUSE	002, 008, 155, 227, [138 279]
ZENITH	014, 027, 036, 041, 073, 085, 097, 104, 113, 121, 133, 136, 153, 226, 227, 247, 266, 288, 310, 338, 358, [039 252] [153 245]
<b>TV/DVD COMBO BRANDS</b>	<b>TV/DVD COMBO BRANDS</b>
ADVENT	899
APEX	[214 401]
AXION	[177 896]
BROKSONIC	394
CHANGHONG	[214 401]
CLASSIC	[214 401]
EMERSON	456
FUNAI	456
INSIGNIA	456
JVC	901
KONKA	412, 413
MAGNAVOX	456
PANASONIC	437
PHILIPS	456, [189 458]
SEARS	394
SYLVANIA	456
SYMPHONIC	456
TOSHIBA	394, 902
<b>DVR/CABLE COMBO BRANDS</b>	<b>DVR/CABLE COMBO BRANDS</b>
PIONEER	506
ROGERS	506
SCIENTIFIC ATLANTA	506
TIME WARNER	506
<b>DVR/DVD COMBO BRANDS</b>	<b>DVR/DVD COMBO BRANDS</b>
PANASONIC	387
TOSHIBA	890, 908

<b>DVD PLAYER BRAND</b>	<b>DVD PLAYER CODES</b>
-------------------------	-------------------------

ADVENT	899
AFREEY	417
AIWA	376, 414
AKAI	357, 395, 435
AMES	431
APEX	386, 390, 391, 392, 401, 424, 430, 436, 439, 445, 457, 459
A-TREND	393
AUDIOVOX	896
AXION	896
B & K	898
BLAUPUNKT	430
BODYSONIC	417
BOSE	672
BROKSONIC	394
CHANGHONG	401
CINEVISION	405
CLASSIC	401, 431
COBY	317
CRITERION	448
CURTIS INTERNATIONAL	906
CYBERHOME	393
DAEWOO	440, 441, 444
DENON	362, 400, 421
DENZEL	428
DIGITREX	445
DISNEY	458
DUAL	428, 446, 447
DVD 2000	402
ELTA	434, 435
EMERSON	396, 405, 456, 458
FISHER	378, 416
FUNAI	456, 458
GE	403, 409, 430
GOLDSTAR	396, 405

<b>GO-VIDEO</b>	407, 426, 431, 455
<b>GRANDIENTE</b>	415

<b>GREENHILL</b>	430
<b>HAAZ</b>	451, 452
<b>HARMAN KARDON</b>	427
<b>HITACHI</b>	404, 407, 419, 428
<b>HITEKER</b>	445
<b>INFINITY</b>	417
<b>INSIGNIA</b>	405, 456
<b>INITIAL</b>	430
<b>INTEGRA</b>	422, 442
<b>JBL</b>	427
<b>JVC</b>	368, 406, 418, 901
<b>KENWOOD</b>	400, 429
<b>KISS</b>	428
<b>KLH</b>	430
<b>KONKA</b>	372, 373, 374, 375, 410, 411, 412, 413
<b>KOSS</b>	415
<b>LASONIC</b>	451, 454
<b>LENOXX</b>	435
<b>LG</b>	396, 405
<b>LINN</b>	443
<b>LITEON</b>	318
<b>MAGNAVOX</b>	360, 370, 398, 408, 456, 900, 903, 904
<b>MARANTZ</b>	360, 396, 398, 405, 408, 423, 903
<b>MEMOREX</b>	446
<b>MICROSOFT</b>	403, 409
<b>MINTEK</b>	430
<b>MITSUBISHI</b>	364, 402
<b>MUSTEK</b>	431
<b>NAD</b>	396, 405, 433
<b>NAKAMICHI</b>	432
<b>NESA</b>	430

<b>NORCENT</b>	317, 318, 319, 905, 907
<b>ONKYO</b>	422, 892
<b>OPTIMUS</b>	404
<b>ORION</b>	394
<b>ORITRON</b>	377, 415
<b>PANASONIC</b>	362, 363, 400

<b>PACIFIC</b>	446
<b>PHILIPS</b>	360, 362, 370, 387, 396, 398, 400, 408, 423, 437, 755, 891
<b>PHILIPS-MAGNAVOX</b>	398, 408, 423, 900, 904
<b>PIONEER</b>	366, 403, 404, 893, 897
<b>POLAROID</b>	385
<b>POLK AUDIO</b>	398, 408, 903
<b>PORTLAND</b>	435
<b>PROLINE</b>	415
<b>PROSCAN</b>	365, 403, 409
<b>RADIOSHACK</b>	404, 443, 449, 453, 894, 895
<b>REOC</b>	451
<b>RCA</b>	365, 403, 409, 430, 443, 449, 453, 895
<b>ROTEL</b>	406
<b>SABA</b>	894
<b>SAMSUNG</b>	369, 407, 454, 455
<b>SAMPO</b>	417
<b>SANSUI</b>	394
<b>SANYO</b>	416
<b>SEARS</b>	394
<b>SEG</b>	428
<b>SHARP</b>	359, 397
<b>SHERWOOD</b>	425
<b>SHINCO</b>	430
<b>SHINSONIC</b>	430
<b>SONY</b>	320, 321, 322, 361, 389, 399, 909
<b>SYLVANIA</b>	456, 458
<b>SYMPHONIC</b>	456, 458

TEAC	404
TECHNICS	400
TECHWOOD	433
TEVION	388, 446, 447, 448, 449, 450, 451, 452
THETA DIGITAL	404
TOSHIBA	360, 394, 398, 436, 447, 890, 902, 908
UNITED	449
WHARFEDALE	417, 442
WHITE WESTINGHOUSE	458
X-BOX	409

YAMAHA	362, 400, 420, 900, 904
YAMAKAWA	428, 438
ZENITH	358, 367, 396, 405, 437
<b>DVD RECORDER BRANDS</b>	<b>DVD RECORDER CODES</b>
	Where codes are shown with the brackets, each one can be used if you have 2 or more of the same device.
GO-VIDEO	431
HITACHI	419
MAGNAVOX	[900], [904]
MUSTEK	431
PANASONIC	387
PHILIPS	[900], [904]
PHILIPS-MAGNAVOX	[900], [904]
PIONEER	897
POLARIOD	385
RCA	409
SONY	[302], [321], [322]
YAMAHA	[900], [904]
<b>DIGITAL VIDEO RECORDER/PERSONAL VIDEO RECORDER BRANDS</b>	<b>DIGITAL VIDEO RECORDER/PERSONAL VIDEO RECORDER CODES</b> Where codes are shown with the brackets, each one can be used if you have 2 or more of the same device.
AT&T	373
PANASONIC	373
PHILIPS	[344], [345], [371]
PROSCAN	403

RCA	403, 409
REPLAY TV	373
SONIC BLUE	373
SONY	372, 372, 657
TiVo	344, 345, 371, 372, 657, 908
TOSHIBA	908
<b>HOME AUTOMATION BRAND</b>	<b>HOME AUTOMATION CODES</b>
X10	881
<b>HOME THEATER IN A BOX BRAND</b>	<b>HOME THEATER IN A BOX CODES</b>
AIWA	[414 839]
APEX	436
BOSE	672
CRITERION	448
KOSS	415

NORCENT	907
ONKYO	892
PANASONIC	891
PHILIPS	755
PIONEER	893
RADIO SHACK	449, 894, 895, [453 879]
RCA	449, 895, [453 879]
SABA	894
SAMSUNG	454
SONY	909
TEVION	448
ZENITH	[405 787]
<b>HDTV Television Brands</b>	<b>HDTV Television Codes</b>
HITACHI 61HDX98B	632
HUGHES HTL-HD	632
MITSUBISHI SR-HD5	632
MITSUBISHI SRHD400	632
MITSUBISHI SRHD500	632
PHILIPS DSHD800R	632

PIONEER SH-D505	604
PROSCAN PSHD105	636
RCA PSHD105	636
RCA DTC-100	636
RCA DTC-210	636
RCA HD65W20	658
SAMSUNG SIR-T165	583
SAMSUNG SIR-T351	583
SONY SATHD100	623
SONY SATHD200	623
SONY SATHD300	623
TOSHIBA DST3000	641
TOSHIBA DST3100	641
TOSHIBA DW65X91	641
ZENITH HDSAT420	634
ZENITH HDSAT520	634
ZENITH DTV1080	634
<b>LASER DISC PLAYER BRAND</b>	<b>LASER DISC PLAYER CODES</b>

DENON	285, 305
PIONEER	285, 305
PROSCAN	288, 308
RCA	288, 308
SANYO	212, 232
SONY	303, 323
ZENITH	212, 323
<b>Plasma, LCD &amp; Panel Television Brands</b>	<b>Plasma, LCD &amp; Panel Television Codes</b>
BENQ	081, 083
CORNEA	050
DUKANE	059, 072
ELITE VIDEO	197
FUJITSU	197
GATEWAY	046

HAIER	081
HITACHI	059, 072
INTEGRA	181
JVC	026
LG	050
LUCE	055
MARANTZ	181
MEGATRON	059
MITSUBISHI	005, 151
MONIVISION	036
NEC	181
NET TV	046, 124
NORCENT	043, 216
PANASONIC	170
PHILIPS/MAGNAVOX	204
PIONEER	072, 181
PRINCETON GRAPHICS	099
RCA	031
RUNCO	181
SAMPO	046, 124
SAMSUNG	007, 076, 077
SANYO	097
SHARP	063

SONY	013, 128
TATUNG	081, 198
TEVION	198
TOSHIBA	170, 181
VIEWSONIC	046, 072
VIKING	174
VIZIO	081
YAMAHA	170
ZENETH	050, 059, 078, 131

<b>SATELLITE/DTV/WebTV RECEIVER BRAND</b>	<b>SATELLITE/DTV/WebTV CODES Where codes are shown with the brackets, each one can be used if you have 2 or more of the same device.</b>
AMPLICA	495, 575
BELL EXPRESSVU	647, 654
CHANNEL MASTER	497, 498, 499, 577, 578, 579
CHAPPARAL	480, 481, 500, 560, 561
CHEYENNE	481, 561
DRAKE	482, 494, 507, 562, 574, 587
DISH TV	576, 586, 613, 616, 621, 622, 623, 629, 630, 632, 634, 636, 638, 641, 652, 653, 657, 659
DISH NETWORK	548, 588, 589, 590, 628, [647], 648, 654, [655]
DISHPRO	568, 582, 588, 589, 590, 654
DX ANTENNA	488, 502, 568, 582
ECHOSPHERE	548, 628
ECHOSTAR	508, 509, 510, 548, 588, 589, 590, 628, [647], 654, [655]
FUJITSU	511, 512, 591, 592
GE	542, 556, 622, 636, 637, 649, 650, 651, 652, 653
GEMINI	595
GENERAL INSTRUMENTS	484, 485, 486, 513, 562, 563, 564, 565, 564, 565, 566, 593, [627], 640, [642], [643], [644], 645, 648
DSS HITACHI	552, 561, 629, 630, 632, 638, 641
DSS HUGHES SATELLITE	549, 550, 552, 553, 558, 621, [629], [630], [632], 633, [638], 641
JANEIL	516, 597
JERROLD	517, 597
JVC	612, 628, 648
KENWOOD	518, 598
LUXOR	519, 599
DSS MAGNAVOX	559, 576, 612, 639
MACOM STATE	520, 600
mitsubishi	629, 630, 632, 638, 641

MOTOROLA	648
NORSTAT	521, 522, 601
PACE	614, 615, 646
DSS PANASONIC	546, 586, 596, 626
PANSAT	584

PRIMESTAR	547, 627, 640
PHILIPS	576, 612, 621, 629, 630, 632, 638, 639, 641
PHILIPS/ MAGNAVOX	559, 576, 612, 639
PIONEER	504, 584, 604
PROSCAN	542, 556, 622, 636, 637, 650
DSS RCA	542, 556, 557, 622, 636, 637, 649, 650, 651, 652, 653, 658
REALISTIC	487, 523, 567, 603
SAMSUNG	583, 594, 613, 616
SCIENTIFIC ATLANTA	527
SHARP	604
SIERRA I II III	481, 561
SKY NETWORK	614, 615, 646
DSS SONY	543, 585, 623, 657, 659
STARCHOICE	627, 640, 645
STAR SIGHT	553, 633
STAR TRAK	528, 608
STS	488, 489, 490, 491, 568, 570, 571
SUPER GUIDE	529, 609
TOSHIBA	492, 562, 572, 574, 587, 595, 634, 635, 641, 646, 656
TOSHIBA DSS	544, 545, 551, 624, 625, 631
ULTIMATE TV	653, 659
UNIDEN	493, 531, 573, 611, 633
DSS UNIDEN	553, 633
UNITED	597
VIDEO CIPHER II	494, 574
WEB TV	585, 612
ZENITH	482, 483, 494, 507, 554, 555, 566, 562, 563, 574, 587, 595, 615, 617, 634, 635, 646, 656
<b>TELEVISION BRAND</b>	<b>TELEVISION CODES</b>
ABEX	185, 172
ACME	003, 010, 021, 039, 049, 050
ADA	018, 025, 004, 007, 016
ADC	001, 002, 004, 005, 003, 009
ADMIRAL	001, 173, 020, 226

ADVENT	176, 899
ADVENTURA	174
AIKO	016, 058
AIWA	195, 196, 227, 269
ALLERON	051
AMARK	020
AMTRON	053
AKAI	002, 150, 254
ALLERON	046, 051
AMARK	020
AMTRON	038, 053
AMSTRAD	189
ANAM NATIONAL	003, 025, 038, 042, 053, 193
AOC	004, 005, 006, 007, 009, 014, 132, 156, 175, 176, 187
APEX	214, 215, 216, 401
ARCHER	020
AUDIOVOX	038, 053
AXION	177, 896
BANG & OLUFSEN	190
BELCOR	004
BELL & HOWELL	000, 001, 031, 049, 083, 162
BENQ	081, 083
BRADFORD	038, 053
BROKSONIC	136, 147, 250, 257, 310, 394
BROKWOOD	004
CANDLE	004, 006, 008, 009, 174
CAPEHART	175
CELEBRITY	002
CENTURION	009
CETRONIC	042
CHANGHONG	214, 401
CITIZEN	001, 004, 006, 008, 009, 016, 038, 042, 053, 058, 105, 109, 171, 174, 177, 189
CLAIRTONE	014, 176
CLASSIC	042, 214, 401

CLP	059
COLOR VOICE	010

COLORTYME	004, 006, 009, 010
CONCERTO	004, 006, 009
CONCIERGE	121
CONTEC/CONY	012, 013, 014, 038, 042, 053, 176
CORNEA	050
CRAIG	038, 042, 053
CROSLEY	062
CROWN	038, 042, 053, 171
CURTIS MATHES	000, 001, 004, 006, 009, 015, 031, 049, 105, 109, 162, 171, 130, 358,
CTX	020
CXC	038, 042, 053
DAEWOO	004, 005, 006, 009, 010, 016, 017, 018, 019, 039, 042, 058, 080, 082, 083, 085, 097, 100, 126, 127, 130, 138, 171, 252, 279,
DAYTRON	004, 006, 009, 171
DIMENSIA	000, 031
DUKANE	059, 072
DUMONT	004, 121
DYNASTY	042
ELEKTRA	001
ELECTROBAND	002, 014
ELECTROHOME	003, 004, 009, 022, 133, 254
ELITE VIDEO	197
EMERSON	004, 009, 014, 021, 023, 024, 025, 026, 027, 030, 032, 033, 034, 035, 036, 037, 038, 039, 040, 041, 042, 043, 044, 045, 046, 049, 051, 053, 116, 135, 147, 177, 179, 189, 198, 227, 233, 250, 252, 254, 257, 265, 266, 310, 325, 456
ENVISION	004, 009
FISHER	012, 013, 049, 050, 110, 180, 209, 268
FUJITSU	046, 051, 197
FUNAI	042, 046, 051, 053, 155, 189, 198, 227, 456
FUTURETEC	042, 053
GE	000, 003, 004, 009, 015, 022, 031, 044, 052, 054, 055, 087, 092, 103, 107, 125, 164, 181, 342
GIBRALTER	004, 121
GOLDSTAR	004, 005, 009, 012, 056, 057, 080, 133, 155, 156, 172, 227, 338

<b>GRUNDY</b>	046, 051, 053
<b>GUESTVISION</b>	201
<b>HAIER</b>	081, 216, 217
<b>HALLMARK</b>	004, 009
<b>HARVARD</b>	053
<b>HITACHI</b>	001, 004, 009, 012, 013, 059, 060, 061, 072, 088, 091, 137, 139, 140, 141, 142, 143, 144, 145, 146, 179, 210

<b>IMA</b>	053
<b>INFINITY</b>	062, 288
<b>INSIGNIA</b>	456
<b>INTEGRA</b>	181
<b>INTEQ</b>	121
<b>JANEIL</b>	174
<b>JBL</b>	062
<b>JCB</b>	002
<b>JC PENNY</b>	000, 004, 005, 008, 009, 012, 015, 022, 030, 031, 052, 054, 055, 063, 087, 105, 107, 109, 172, 181
<b>JENSEN</b>	004, 009
<b>JVC</b>	013, 012, 026, 054, 055, 060, 065, 067, 069, 089, 141, 197, 247, 901
<b>KAWASHO</b>	002, 004, 009
<b>KAYPANI</b>	175
<b>KEC</b>	042
<b>KENWOOD</b>	004, 009, 133
<b>KLOSS NOVABEAM</b>	068, 069, 174
<b>KONKA</b>	011, 016, 047, 053, 066, 157, 158, 176. 412, 413
<b>KTV</b>	014, 021, 042, 053, 070, 116, 177
<b>KURAZAI</b>	001
<b>LG</b>	004, 005, 009, 012, 050, 057, 080, 156, 227, 338
<b>LODGENET</b>	000, 001, 031, 202
<b>LOEWE</b>	062, 211
<b>LOGIK</b>	000, 001, 031
<b>LUCE</b>	055
<b>LUXMAN</b>	004, 009
<b>LXI</b>	000, 004, 009, 015, 031, 049, 062, 107, 109, 181, 227
<b>MAGNAVOX</b>	004, 008, 009, 062, 068, 069, 074, 075, 076, 077, 089, 133, 141, 163, 165, 226, 288, 456

<b>MAJESTIC</b>	000, 001, 031
<b>MARANTS</b>	062
<b>MARANTZ</b>	004, 009, 062, 181
<b>MATSUI</b>	062
<b>MEGATRON</b>	004, 009, 059
<b>MEI</b>	014
<b>MEMOREX</b>	000, 001, 004, 009, 031, 046, 049, 051, 135, 268, 310
<b>MGA</b>	004, 005, 009, 012, 022, 046, 051, 133, 141, 180
<b>MIDLAND</b>	015, 031, 054, 055, 107, 121, 172, 181
<b>MINUTZ</b>	052

<b>mitsubishi</b>	004, 005, 009, 022, 046, 051, 081, 089, 132, 133, 141, 151, 180, 254
<b>MONIVISION</b>	036
<b>MONTGOMERY WARD</b>	000, 001, 131
<b>MOTOROLA</b>	002, 003, 173
<b>MTC</b>	004, 005, 009, 014, 105, 109
<b>MULTITECH</b>	053
<b>MULTIVISION</b>	084
<b>NAD</b>	004, 009, 109, 185
<b>NEC</b>	003, 004, 005, 009, 010, 085, 089, 095, 141, 181
<b>NET TV</b>	046, 124
<b>NIKEI</b>	042
<b>NIKKO</b>	004, 009, 058
<b>NORCENT</b>	043, 216
<b>NTC</b>	058
<b>ONCOMMAND</b>	201
<b>ONKING</b>	042
<b>ONWA</b>	042, 053
<b>OPTIMUS</b>	170, 185, 374, 381
<b>OPTONICA</b>	020, 095, 173
<b>ORION</b>	035, 121, 135
<b>PANASONIC</b>	003, 054, 055, 062, 070, 148, 149, 170, 171, 374, 381, 437
<b>PHILCO</b>	003, 004, 005, 008, 009, 062, 068, 069, 074, 075, 077, 133
<b>PHILIPS</b>	003, 004, 006, 008, 062, 068, 069, 074, 075, 076, 086, 087, 089, 133, 141, 163, 183, 184, 189, 204, 205, 206, 207, 208, 212, 213, 288

<b>PHILIPS/MAGNAVOX</b>	062, 183, 184, 204, 207, 208, 213, 226, 288
<b>PILOT</b>	004
<b>PIONEER</b>	004, 009, 072, 090, 179, 181, 185
<b>PORTLAND</b>	004, 005, 009, 058, 138
<b>PRECISION</b>	166
<b>PRICE CLUB</b>	105
<b>PRINCETON GRAPHICS</b>	020, 099
<b>PRISM</b>	054, 055
<b>PROSCAN</b>	000, 015, 031, 107, 181
<b>PROTON</b>	004, 009, 093, 175, 186, 192
<b>PULSAR</b>	004, 121
<b>PULSER</b>	004
<b>QUASAR</b>	003, 054, 055, 062, 070, 148, 170, 171, 374, 381
<b>RADIO SHACK/REALISTIC</b>	000, 004, 009, 031, 041, 042, 048, 049, 053, 095, 133, 155, 170, 172, 194, 227, 342

<b>RCA</b>	000, 003, 004, 005, 007, 009, 011, 031, 048, 054, 078, 082, 083, 094, 096, 098, 099, 100, 101, 102, 103, 107, 113, 129, 133, 167, 179, 181, 187, 188, 191, 194, 342
<b>REALISTIC</b>	000, 004, 009, 012, 031, 041, 042, 048, 049, 053, 095, 155, 170, 172, 227
<b>RHAPSODY</b>	014
<b>RUNCO</b>	111, 121, 181
<b>SAMPO</b>	004, 009, 012, 046, 124, 172, 175
<b>SAMSUNG</b>	004, 005, 007, 009, 012, 015, 076, 077, 080, 104, 105, 106, 109, 133, 172, 358
<b>SAMSUX</b>	009
<b>SANSUI</b>	135, 136, 310
<b>SANYO</b>	004, 012, 013, 049, 097, 108, 110, 180, 209, 268
<b>SCOTCH</b>	004, 009
<b>SCOTT</b>	004, 009, 024, 035, 042, 046, 051, 053
<b>SEARS</b>	000, 004, 009, 012, 013, 015, 031, 046, 049, 051, 062, 105, 107, 109, 110, 133, 180, 181, 189, 394
<b>SHARP</b>	004, 006, 009, 020, 063, 079, 095, 111, 112, 114, 122, 123, 124, 173, 226, 266
<b>SHOGUN</b>	004
<b>SIGNATURE</b>	000, 001, 023, 031
<b>SIMPSON</b>	008
<b>SONIC</b>	014
<b>SONY</b>	002, 006, 013, 071, 128, 380

<b>SOUNDESIGN</b>	004, 008, 009, 042, 051, 053, 042, 046
<b>SPECTRAVISION</b>	203
<b>SQUAREVIEW</b>	189
<b>SSS</b>	004, 042, 053
<b>STARLITE</b>	053
<b>STAR SIGHT</b>	064
<b>SUPRA</b>	004, 082
<b>SUPREMACY</b>	174
<b>SUPREME</b>	002
<b>SVA</b>	216
<b>SYLVANIA</b>	004, 008, 009, 062, 068, 069, 074, 075, 076, 077, 133, 135, 141, 161, 163, 189, 198, 227, 456
<b>SYMPHONIC</b>	024, 033, 053, 189, 198, 227, 456
<b>TANDY</b>	020, 173
<b>TATUNG</b>	003, 081, 198
<b>TECHNICS</b>	004, 009, 054, 055
<b>TECHWOOD</b>	004, 009, 054, 055
<b>TEKNIKA</b>	000, 001, 004, 005, 008, 009, 013, 031, 042, 046, 051, 053, 058, 076, 105, 109, 170, 174
<b>TELECATION</b>	117
<b>TELERENT</b>	000, 001, 031

<b>TERA</b>	004, 186
<b>TEVION</b>	198
<b>TMK</b>	004, 009
<b>TOSHIBA</b>	012, 013, 049, 089, 095, 105, 109, 117, 118, 120, 141, 159, 170, 178, 181, 260, 358, 394, 902
<b>UNIVERSAL</b>	052, 087
<b>VICTOR</b>	060
<b>VIDTECH</b>	004, 005, 009
<b>VIEWSONIC</b>	046, 072
<b>VIKING</b>	174
<b>VIZIO</b>	081
<b>WARDS</b>	000, 001, 004, 005, 008, 009, 024, 031, 033, 046, 051, 052, 062, 068, 069, 074, 075, 076, 087, 095, 119, 133
<b>WHITE WESTINGHOUSE</b>	080, 097, 100, 130, 138, 155, 227, 279
<b>YAMAHA</b>	004, 005, 009, 133, 170
<b>YUPITERU</b>	042

ZENETH	000, 001, 004, 009, 023, 038, 039, 050, 058, 059, 064, 078, 091, 111, 121, 131, 134, 135, 136, 153, 226, 227, 245, 247, 252, 266, 288, 310, 338, 358
<b>VCR BRAND</b>	<b>VCR CODES</b>
ACCELE	354
ADMIRAL	206, 226
ADVENTURA	231, 251
AIKO	232, 252
AIWA	207, 231, 249, 227, 245, 251, 269
AKAI	208, 209, 210, 211, 213, 227, 228, 229, 230, 231, 233, 234, 254, 303, 316, 317, 336, 337
ALLERGRO	223, 227, 309, 243, 247, 329
AMERICAN HIGH	226, 265, 246, 285, 292, 329
ASHA	218, 354, 359
AT&T	373
AUDIO DYNAMICS	214, 328, 234, 376, 377
AUDIOVOX	219, 239, 245, 348
BELL & HOWELL	248, 268
BEAUMARK	218, 354, 359
BROKSONIC	217, 230, 236, 237, 250, 256, 257, 269, 290, 237, 250, 256, 289, 310, 394
CALIX	219, 239, 254
CANDLE	214, 218, 219, 220, 221, 222, 224, 234, 239, 240, 241, 242, 244, 245, 354, 359
CANNON	225, 226, 265, 292, 319, 320, 246, 285, 339, 340
CAPEHART	309, 315, 329
CARVER	267, 287
CCE	232, 266, 252, 286, 356

CINEVISION	245
CITIZEN	214, 218, 219, 220, 221, 222, 224, 232, 234, 239, 240, 241, 242, 244, 245, 252, 354, 359
COLORTYME	214, 234
COLT	266, 286, 356
CRAIG	218, 219, 228, 266, 239, 245, 248, 286, 354, 356, 359
CURTIS MATHES	205, 207, 214, 218, 221, 225, 226, 229, 265, 225, 227, 234, 241, 246, 249, 285, 287, 292, 320, 334, 340, 354, 358, 359
CYBERNEX	218, 354, 359
DAEWOO	220, 222, 224, 230, 231, 232, 233, 315, 240, 242, 244, 250, 251, 252, 253, 279, 334
DAYTRON	315

<b>DBX</b>	214, 234, 328, 334, 348, 376, 377
<b>DIMENSIA</b>	205, 225, 255
<b>DYNATECH</b>	207, 227, 231, 251
<b>ELECTROHOME</b>	219, 234, 245, 277, 251, 239, 254
<b>ELECTROPHONIC</b>	219, 239, 245
<b>EMERSON</b>	207, 211, 217, 219, 220, 226, 227, 229, 230, 231, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 248, 249, 250, 251, 252, 254, 255, 256, 257, 259, 261, 262, 263, 265, 266, 268, 269, 270, 272, 285, 289, 290, 292, 301, 310, 321, 325, 330, 341, 354, 359, 456
<b>FISHER</b>	214, 228, 234, 248, 253, 254, 255, 267, 234, 248, 267, 268, 273, 274, 275, 287, 304
<b>FUJI</b>	209, 226, 265, 229, 246, 285, 292
<b>FUNAI</b>	207, 213, 231, 227, 233, 251, 456
<b>GARRARD</b>	231, 251
<b>GE</b>	205, 218, 225, 226, 246, 258, 265, 278, 285, 292, 311, 320, 322, 325, 340, 342, 345, 354, 359
<b>GOLDSTAR</b>	214, 219, 227, 245, 234, 239, 326, 338, 346
<b>GRADIENTE</b>	231, 251
<b>GO-VIDEO</b>	339, 348, 345, 359, 368, 375, 407, 426, 455
<b>HARLEY DAVIDSON</b>	231, 251
<b>HARMON KARDON</b>	214, 234, 254, 273, 293
<b>HARWOOD</b>	266, 286, 356
<b>HEADQUARTER</b>	248, 268
<b>HITACHI</b>	207, 227, 280, 282, 260, 262, 303, 312, 316, 322, 325, 327, 336, 345, 347, 349, 350, 369, 370
<b>HI-Q</b>	228, 248
<b>INFINITY</b>	288
<b>INSIGNIA</b>	245
<b>INSTANT REPLAY</b>	213, 226, 227, 265, 233, 246, 285, 292
<b>INTEQ</b>	219, 239, 245
<b>JCL</b>	226, 265, 246, 285, 292
<b>JC PENNY</b>	214, 218, 219, 225, 234, 239, 245, 248, 260, 265, 268, 280, 285, 292, 303, 312, 328, 316, 320, 323, 332, 336, 340, 343, 348, 354, 359, 369, 376, 377

<b>JENSEN</b>	260, 280, 303, 316, 336, 369
<b>JVC</b>	214, 227, 234, 247, 248, 316, 328, 234, 247, 268, 303, 336, 348, 376, 377, 418
<b>KENWOOD</b>	214, 221, 248, 268, 316, 328, 234, 247, 268, 303, 336, 348, 376, 377
<b>KLH</b>	266, 336, 286, 356
<b>KODAK</b>	219, 226, 245, 239, 246, 265, 285, 292



<b>PHILIPS</b>	226, 246, 265, 267, 280, 285, 287, 288, 292, 300, 311, 328, 329, 331, 333, 344, 345, 349, 351, 371, 378, 383, 456
<b>PHILIPS/ MAGNAVOX</b>	226, 287, 288, 328, 333
<b>PILOT</b>	219, 239, 245
<b>PIONEER</b>	260, 280, 285, 286, 305, 306, 328, 343, 348, 369, 376, 377
<b>PORTLAND</b>	221, 222, 224, 315, 241, 242, 244
<b>PROSCAN</b>	205, 225, 308
<b>PROTEC</b>	266, 286, 356
<b>PULSAR</b>	309, 329
<b>QUARTER</b>	248, 268
<b>QUARTZ</b>	248, 268
<b>QUASAR</b>	225, 226, 265, 320, 330, 246, 285, 292, 340, 350, 363, 374, 381
<b>RADIO SHACK/REALISTIC</b>	205, 206, 207, 218, 219, 226, 228, 231, 234, 248, 254, 255, 265, 280, 314, 317, 320, 341, 342, 343, 225, 226, 227, 239, 246, 248, 251, 254, 268, 274, 275, 285, 300, 337, 340, 342, 359, 361, 362, 363, 225, 226, 227, 239, 246, 248, 251, 254, 268, 274, 275, 285, 300, 337, 340, 342, 359, 361, 362, 363
<b>RADIX</b>	219, 239, 245
<b>RANDEX</b>	219, 239, 245
<b>RCA</b>	205, 208, 218, 225, 226, 227, 228, 239, 245, 246, 248, 251, 254, 260, 265, 268, 274, 278, 280, 285, 287, 288, 289, 291, 292, 293, 294, 295, 296, 300, 307, 308, 309, 311, 312, 313, 314, 315, 316, 320, 325, 330, 332, 335, 337, 340, 342, 345, 350, 354, 359, 361, 362, 363, 369
<b>REPLAY</b>	353, 373
<b>RICOH</b>	333, 353
<b>RUNCO</b>	309, 329
<b>SAMSUNG</b>	210, 218, 220, 230, 238, 240, 258, 260, 278, 280, 317, 334, 337, 339, 354, 358, 359, 369, 455
<b>SANKY</b>	206, 309, 226, 329
<b>SANSUI</b>	297, 316, 328, 336, 348
<b>SANYO</b>	218, 228, 248, 267, 268, 304, 354, 359
<b>SCOTT</b>	217, 220, 230, 237, 240, 243, 250, 257, 263, 270, 290, 298, 318, 321, 341
<b>SEARS</b>	219, 226, 228, 239, 245, 246, 248, 253, 254, 255, 260, 265, 267, 268, 273, 274, 275, 280, 285, 287, 292, 312, 323, 332, 343, 363, 369, 394
<b>SHARP</b>	206, 207, 222, 226, 227, 234, 239, 242, 246, 248, 254, 266, 268, 273, 274, 275, 280, 285, 287, 300, 340, 341, 360, 361
<b>SHINTOM</b>	209, 229, 260, 266, 280, 286, 333, 337, 353, 356, 357, 369
<b>SHOGUN</b>	218, 354, 359
<b>SIGNATURE</b>	207, 227, 354
<b>SINGER</b>	226, 265, 266, 246, 285, 286, 292, 356
<b>SONIC BLUE</b>	373

<b>SONY</b>	209, 229, 304, 323, 324, 333, 344, 345, 346, 352, 353, 364, 365, 366, 372, 379, 380, 389
<b>STS</b>	226, 260, 265, 312, 246, 280, 285, 292, 332, 369
<b>SYLVANIA</b>	207, 227, 231, 233, 251, 265, 267, 270, 285, 287, 290, 320, 340, 349, 456

<b>SYMPHONIC</b>	207, 231, 227, 233, 236, 251, 456
<b>TANDY</b>	207, 248, 227, 268
<b>TASHIKO</b>	219, 239, 245
<b>TATUNG</b>	303, 316, 336
<b>TEAC</b>	207, 231, 316, 227, 251, 303, 336
<b>TECHNICS</b>	226, 265, 314, 246, 285, 292
<b>TEKNIKA</b>	207, 219, 226, 227, 231, 239, 245, 246, 251, 265, 285, 292, 305, 325
<b>TiVo</b>	351, 352, 371, 372
<b>TMK</b>	218, 229, 252, 249, 272, 301, 354, 359
<b>TOSHIBA</b>	220, 240, 254, 260, 261, 267, 270, 274, 287, 290, 298, 318, 321, 341, 358, 369, 902,
<b>TOTEVISION</b>	218, 219, 239, 245, 354, 359
<b>UNITECH</b>	218, 354, 359
<b>VECTOR RESEARCH</b>	214, 220, 221, 328, 234, 240, 241, 348, 376, 377
<b>VICTOR</b>	328, 348, 376, 377
<b>VIDEO CONCEPTS</b>	214, 220, 221, 234, 328, 240, 254, 274, 280, 287, 290, 318, 341, 376, 377
<b>VIDEOSONIC</b>	218, 354, 359
<b>WARDS</b>	206, 207, 218, 219, 220, 225, 226, 227, 228, 231, 234, 239, 240, 245, 246, 248, 251, 254, 260, 265, 266, 280, 285, 306, 312, 321, 354, 369
<b>WHITE WESTINGHOUSE</b>	207, 213, 227, 233, 251, 279, 292, 356
<b>XR-1000</b>	226, 231, 265, 266, 246, 251, 285, 286
<b>YAMAHA</b>	214, 234, 248, 303, 316, 328, 234, 268, 336, 348, 376, 377
<b>ZENITH</b>	209, 212, 215, 219, 223, 226, 227, 229, 232, 235, 239, 243, 245, 247, 252, 266, 281, 283, 284, 288, 290, 309, 310, 324, 328, 329, 333, 338, 344, 347, 348, 353, 358, 368, 370, 376, 377