





Replacement VHF Antenna

INSTALLATION:

1. Antenna snaps into place on back of TV. (Fig. 1)
 2. If your TV has a single threaded F-jack, then you will need a 300 ohm to 75 ohm transformer (not included) to connect antenna to TV. (Fig. 2)
- For other TV antenna connections not shown, refer to the manufacturer's instructions for your specific TV.



Antena de Reemplazo de VHF

INSTALACIÓN:

1. La antena se engancha en su lugar en la parte posterior del TV. (Fig. 1)
2. Si su TV tiene un solo enchufe roscado F, entonces usted necesitará un transformador de 300 ohmios a 75 ohmios (no incluido) para conectar la antena al TV (Fig 2). Para otras conexiones de antenas, no mostradas, en la parte posterior de su TV, remitirse a las instrucciones del fabricante de su TV específico.